

Our goal is to make the install a breeze. Please read the entire guide before beginning. Something NEW for 2020, is the use of Smart Phone integrations by scanning QR codes with your phone's camera or a QR code app. Any time you see a  that tool is available on our [Amazon tool page](#). If a Video tutorial has been created for this product, you will find it [here](#). If you have a tech question, you can [text us here](#).

Proper maintenance of the clutch cable is crucial in the actual installation of the six shooter.

1. Loosen the lug nuts on the left rear wheel 1/4 turn before jacking the vehicle up.
2. Jack  up the rear of the vehicle and place stands  underneath the chassis.
3. Remove the wheel and place under the chassis as a fail safe.
4. Locate the clutch lever on the transaxle with a cable and factory wing nut.
5. Spray WD40  on the cable and remove the wing nut.
6. Inspect the cable. If the threads are full of dirt and grime, you need to clean the cable. A couple different ways to do this. Use a wire brush  and a cleaning solution or use a 7mm x 1.0 thread chaser .
7. Once the cable is clean and ready to go, apply grease  or anti-seize  to the cable.
8. Raw Six Shooters are made out of steel, so they must be coated  to prevent rust. Black Six Shooters are ready to go.
9. Apply grease/anti-seize  to the back of the nut and the threads.
10. Install onto the cable. As you tighten, check your pedal for free play and engagement. Once the ideal feel is attained, wipe off the residual grease/anti-seize from the cable. This would become a dirt and dust magnet.
11. Re-install the wheel and hand tighten the lugs.
12. Jack up the vehicle, remove the jack stand and lower. Then torque the lugs to factory specs.
13. Enjoy a properly adjusted clutch. Make minor adjustments with ease, now that you have a Six Shooter installed.

Tools you need



Video Tutorials



Tech Support

